

LIP CREAM C.SK.16.41.4HPC

This fragrance-free repair formula with Hyaluronic Acid, Allantoin, Glycerin and Bisabolol instantly relieves feelings of dryness and tightness. Deeply moisturising oils soothe, soften and protect dry and cracked lips bringing them to their natural softness.

Commercial Name	INCI	%
	A	
	Aqua	54,75
	Allantoin	0,30
	Magnesium Sulfate	0,70
	Hydroxyethylcellulose	0,30
PrincipHYAL Signal-10	Hyaluronic Acid	0,25
	В	
	Glycerin	6,00
BiosControl® Evolve CPC	Capryloyl Glycine	1,50
	С	
Olifeel [®] E-Nat WO	Polyglyceryl-3 Polyricinoleate, Polyglyceryl-3 Oleate	6,00
Specifeel® NH Butter Avocado	Persea Gratissima Oil, C10-18 Triglycerides	3,00
Olifeel [®] Pearls	C10-18 Triglycerides	4,00
Olifeel® TD7525	Triolein, Glyceryl Dioleate	10,00
	Simmondsia Chinensis Oil	4,00
	Bisabolol	0,60
ABWax [®] White Beeswax Pearls F.U.	Cera Alba	3,00
	Helianthus Annuus Seed Oil	4,00
	Tocopherol	0,80
	D	
BiosControl® Excel 3231	Butylene Glycol, Clorphenesin, o-cymen-5-ol	0,80
TOTAL		100,00

INGREDIENTS BENEFITS:

- > Olifeel® E-Nat WO, 100% natural emulsifier whit unique rich touch
- > Specifeel® NH Butter Avocado, highly moisturizing and skin softness
- > Olifeel® Pearls, formula stability
- > Olifeel® TD7525, soft touch and gliding effect to the formula
- > PrincipHYAL Signal-10, short-time turbo moisturization, skin regeneration and elasticity
- > ABWax® White Beeswax Pearls FU, formula stability, film-forming and emollient capacity
- > BiosControl® Evolve CPC, enhancer of traditional preservative systems
- > BiosControl® Excel 3231, full spectrum preservative system specific for leave on applications

CHEMICAL PHYSICAL PARAMETERS:

- Appearance: cream
 Colour: white / ivory

MANUFACTURING METHOD

- MANUPACTORING METHOU 1. Prepare Phase A under stirring at 75+/-2°C 2. Prepare Phase B under stirring at 75+/-2°C 3. Prepare Phase C under stirring at 75+/-2°C 4. Put Phase A+B into Phase C slowly under mix and mix until complete

- 5. Cool down at room temperature and add Phase D

The formulation above is based on our best knowledge and is provided only as an indication. The end user must verify himself the applicative characteristics, the stability as well as the existence of a patent. The company ROELMI HPC does not give any guarantee and disclaims all responsibility for the use of this